



## **RAMS-2001 DRIVE CLEAT NOTCHER**

**Capacity 20 Ga. Mild Steel Maximum**

### **OPERATION:**

1. Mount the Drive Cleat Notcher to a secure solid work bench prior to use.
2. Adjust pins to outer location for drive cleats. Relocate pins to inner location for notching ends on hanger material.
3. After sliding in piece, pull down on spring loaded handle to notch.  
\*See product video for more information.

### **MAINTENANCE:**

1. Keep blades and pins free of debris.
2. Occasionally, put a light coat of oil on cutting blades and guide pins, to ensure efficient operation.
3. Shear blades are hardened, but may dull over time. Replacements blades available

### **FOR REPLACEMENT PARTS:**

Please verify part number on our website and then call RAMS Sheet Metal Equipment at 888-326-6481 Ext 4